



Wooden Bird House



Solar Light



Granite Post Covers



Septic Vent Cover Installation Guide



Septic Systems of Maine

650 Old Greene Rd • Lewiston, ME 04240

www.SepticSystemsOfMaine.com

207-782-1620

Order at

www.septicsystemsofmaine.com/products/vent-covers-for-sale/

Our Septic Vent Covers are fully assembled and only need to be attached to an existing 4 inch diameter PVC vent pipe.

1 Locate your existing septic vent pipe and remove the 90 degree elbow or “Candy Cane” top. If the elbow is not glued it may be possible to carefully pull it off the vertical pipe. Be careful not to disconnect any other vent fittings especially underground. If the elbow is glued, you will need to cut the vertical pipe just under the elbow.



Cut here and remove the elbow



2 Clean & deburr the top of the vertical pipe.

3 Slide the Vent Cover over the top of the septic pipe. You may secure it with PVC cement or stainless steel screws.



Optional matching paint is available to cover the septic pipe below the Septic Vent Cover.

Solar Light Activation:

1. Before use remove the plastic cling film from the top of the solar cells.
2. Twist off the top from the light cage. Depending on the model of solar light you may have the following options:
 - a. Locate the on/off switch on the underside of the solar light top and make sure it is switched to the “ON” position.
 - b. Some models of the solar lights have the option of switching to a flickering flame or the bright light.
3. Please allow for a full day of charging in the sun before the light will be fully charged and able to light.